

TT-OACS Series

CENTRAL CHILLER



**Covering Single Zone
Models from 5 - 60 Tons
with CG Control Instrument**



TEMPTEK, INC.

525 East Stop 18 Road Greenwood, IN 46142

317-887-6352 fax: 317-881-1277

Service Department fax: 317-885-8683

www.TempTek.com

E-mail service@TempTek.com

Model: _____

Serial Number : _____

TTOACS *SERIES*

CENTRAL CHILLER

INSTRUCTION MANUAL AIR-COOLED MODELS

COVERING

INSTALLATION OPERATION MAINTENANCE

Covering Single Zone Models from 5 - 60 Tons
with CG Control Instrument



TEMPTEK, INC. 525 East Stop 18 Road Greenwood, IN 46143
317-887-6352 fax: 317-881-1277 Service Department fax: 317-885-8683
Website: www.Temptek.com E-mail: service@Temptek.com

TABLE OF CONTENTS

1.0	GENERAL	7
1.1	Introduction	8
1.2	Safety	8
1.3	Receiving instructions	10
1.4	Efficiency	10
1.5	Clean air act	10
1.6	Water Treatment	11
1.7	Model Designation	11
1.8	Components	12
2.0	INSTALLATION	13
2.1	General	14
2.2	Unit Location	14
2.3	Chilled Water Piping Installation	15
2.4	Air-Cooled Condenser	15
2.5	Make-Up Water Supply Connection	17
2.6	Electrical Connection	17
2.7	Piping Installation (Typical)	20
3.0	OPERATIONS	21
3.1	General	22
3.2	Start Up / Operation Procedure	23
3.3	CG Instrument Operations	27
3.4	Instrument : Main Menu	30
3.5	Instrument : Setpoints Menu	30
3.6	Instrument : Utilities Menu	32
3.7	Instrument : Network Menu	33
3.8	Instrument : Flow Menu (optional)	34
3.9	Instrument : Options Menu	35
3.10	Instrument : Machine Menu	36
3.11	Controls	39
3.12	Pressure Gauges & Alarm Beacon	39
3.13	Shut Down Procedure	40
4.0	TROUBLESHOOTING	41
4.1	Unit Will Not Start	42
4.2	Compressor Hums But Will Not Start	42
4.3	Shuts Off On High Pressure	42
4.4	Shuts Off On Low Pressure	43
4.5	Compressor Shuts Off On Internal Overload	44
4.6	Low or No Process Pressure or Water Flow	44
4.7	Cooling Capacity Inadequate	44
4.8	Sensor	44
4.9	Coolant Pumps	45
4.10	Chiller Controller	45
4.11	Replacement Control Configuration	47



5.0	MAINTENANCE	49
5.1	Warranty Service Procedure	50
5.2	Periodic Preventative Maintenance	50
5.3	Special Maintenance	51
5.4	Solenoid Valve Service	52
5.5	Pump Seal Service	54
5.6	Checking Refrigerant Charge	57
5.7	Proper Cleaning Procedure for Brazed Plate Evaporators	57
6.0	COMPONENTS	59
6.1	Refrigeration Components	60
6.2	Coolant System	62
7.0	RELATED DRAWINGS	63
7.1	Typical Circuit Schematic	64
7.2	Typical Physical Drawing	65
7.3	Typical Press Drip	66
7.4	Typical Vacuum Breaker / Anti-Siphon System	67
7.5	Typical Label Placement Drawing	68
7.6	Typical Panel / Control Station Drawing	69
8.0	APPENDIX	71
8.1	Operations Below 48°F Fluid or 38°F Ambient	72
8.2	Refrigerant Pressure-Temperature Chart	74
8.3	Inhibited Propylene Glycol	75
8.4	Chiller Capacity & Derate Chart	75
8.5	Standard CG Instrument Settings	76
8.6	Probe Calibration : CG Instrument	77
8.7	Status Indicators : CG Instrument	79
8.8	Water Quality	80
8.9	Modbus Registers	82



THIS PAGE INTENTIONALLY BLANK

1.0 GENERAL

- 1.1 Introduction
- 1.2 Safety
- 1.3 Receiving Instructions
- 1.4 Efficiency
- 1.5 Clean Air Act
- 1.6 Water Treatment
- 1.7 Model Designation
- 1.8 Components



1.1 INTRODUCTION


- A. This manual covers TTOACS central chillers from 5 to 210 tons (17.2 to 717.4 kW) of cooling capacity using the CG microprocessor control instrument and fixed displacement scroll compressors and digital scroll compressors. The standard fluid operating temperature range for this chiller is 20°F to 80°F for units using R410A refrigerant. Units using other refrigerants have different standard operating ranges.
- B. If running at a fluid temperature below 48°F or if the chiller will be installed in a climate where the ambient temperature may get below 40°F you must use a water and glycol mixture at a ratio that protects the fluid from freezing to approximately 25°F below the lowest expected set point temperature or the lowest expected ambient temperature whichever is lower. See Section 8.1 and 8.2 of this manual before operating your chiller. Regular testing of your glycol protection is critical.
- C. The intent of this manual is to serve as a guide in the installation, operation and maintenance of your chiller. Improper installation can lead to equipment damage and poor performance. Failure to follow the installation, operation and maintenance instructions may result in damage to the unit that is not covered under the limited warranty. This manual is for standard products. The information contained in this manual is intended to be general in nature. The information is typical only and may not represent the actual unit purchased.
- D. Chemical refrigerants are used in this unit. The refrigerant is sealed and tested in a pressurized system however a system failure will release it. Refrigerant gas can cause toxic fumes if exposed to fire. Install this unit in a well-ventilated area away from open flames. Failure to follow these instructions may result in a hazardous condition. Recover refrigerant to relieve pressure before opening the system. See nameplate for refrigerant type. Do not use non-approved refrigerants or refrigerant substitutes.
- E. Customers should implement a refrigerant management program to document the type and quantity of refrigerant in each chiller. All refrigeration service technicians performing work on this chiller must be licensed and certified.
- F. When calling for assistance from the Manufacturer's Service Department, it is important to know the model and serial number of the particular unit. The model number includes critical unit information which is helpful when troubleshooting operating difficulties. The serial number allows the service team to locate manufacturing and testing records which can have additional information relating to a particular unit.

1.2 SAFETY


- A. It is important to become thoroughly familiar with this manual and the operating characteristics of the unit.
- B. It is the owner's responsibility to assure proper operator training, installation, operation, and maintenance of the unit.
- C. Observe all warning and safety placards applied to the chiller. Failure to observe all warnings can result in serious injury or death to the operator and severe mechanical damage to the unit.




- D. Observe all safety precautions during installation, startup and service of this equipment due to the presence of high voltage and refrigerant charge. Only qualified personnel should install, startup and service this equipment.
- E. When working on this equipment, observe precautions in literature and on tags, stickers and labels located on the equipment. Wear work gloves and safety glasses.



WARNING: This equipment contains hazardous voltages that can cause severe injury or death. Disconnect and lock out incoming power before installing or servicing the equipment.




WARNING: This equipment contains refrigerant under pressure. Accidental release of refrigerant under pressure can cause personal injury and or property damage. Exercise care while working on or around this equipment.



WARNING: Vent all refrigerant relief valves in accordance to ANSI/ASHRAE Standard 15, Safety Code for Mechanical Refrigeration. This equipment should be located within a well-ventilated area. Inhalation of refrigerant can be hazardous to your health and the accumulation of refrigerant within an enclosed space can displace oxygen and cause suffocation

Samples of Warning Labels applied to typical chillers.



WARNING
Hazardous voltage.
 Contact with voltage may cause death or serious injury.
 Always disconnect power to unit prior to servicing.
J5318-02

Alerts users to the danger of high voltage.



WARNING
Moving parts can crush and cut.
 Do not operate with guard removed.
 Follow lock-out procedures before servicing.
J5807-AF

Alerts user to the danger of the rotating condenser fans on air condensed units.



WARNING
Moving parts can crush and cut.
 Do not operate with guard removed.
 Follow lock-out procedures before servicing.
J6009-AF

Alerts user to the danger of belt drive systems on unit with blowers.



This symbol is seen on all chillers to alert user to the danger of the refrigeration system under pressure. System should only be serviced by a licensed technician.

1.3 RECEIVING INSTRUCTIONS

- A. Check the overall condition of the equipment prior to accepting delivery.
- B. Check for visible damage and document any evident damage on the delivery receipt. Check the refrigerant gauges to be sure the system charge is intact. See the chart in section 8.4 for proper pressure readings based on the ambient temperature and refrigerant type used in the chiller. Shipping damage is the responsibility of the carrier.
- C. In order to expedite payment for damages, should they occur, follow proper procedures and keep detailed records. Take photographs of any suspected damage.

1.4 EFFICIENCY

- A. Long term efficiency of operation is largely determined by proper maintenance of the mechanical parts of the unit and the water quality. The Manufacturer recommends filtering the process water to prevent solids from plugging critical parts. The Manufacturer highly recommends that the services of a qualified water treatment specialist be obtained and their recommendations be followed. The Manufacturer accepts no responsibility for inefficient operation, or damage caused by foreign materials or failure to use adequate water treatment.

1.5 CLEAN AIR ACT

- A. Units manufactured after January 1, 2010 may contain refrigerant HFC-410A, HFC-407C, HFC-404A or HFC-134A. Most units manufactured prior to January 1, 2010 contain refrigerant HCFC-22.
- B. It is unlawful for any person in the course of maintaining, servicing, repairing, or disposing of refrigeration equipment to knowingly vent or otherwise dispose of any substance used as a refrigerant in the manner which permits such substance to enter the atmosphere.
- C. Very small releases associated with good faith attempts to recapture, reclaim or recycle such substance shall not be subject to the prohibition set forth in the preceding paragraph.
- D. Customers should implement a refrigerant management program to document the type and quantity of refrigerant in each chiller. All refrigeration service technicians performing work on this chiller must be licensed and certified.
- E. Vent all refrigerant relief valves in accordance to ANSI/ASHRAE Standard 15.



WARNING: Vent all refrigerant relief valves in accordance to ANSI/ASHRAE Standard 15, Safety Code for Mechanical Refrigeration. This equipment should be located within a well-ventilated area. Inhalation of refrigerant can be hazardous to your health and the accumulation of refrigerant within an enclosed space can displace oxygen and cause suffocation.



WARNING: Improper water treatment will void unit warranty.


1.6 WATER TREATMENT

- A. The use of untreated or improperly treated water in a portable chiller may result in scaling, erosion, corrosion, algae or slime.
- B. It is recommended that the services of a qualified water treatment specialist be engaged to determine what water treatment is required.
- C. Advantage assumes no responsibility for equipment failures which result from untreated or improperly treated water.
- D. Do not use deionized water in this unit. Some customized units may be compatible with deionized water. Consult the factory before using deionized water.
- E. If the chiller is installed in an environment where ambient temperatures could be under 35°F and/or if the unit operating set point will be 48°F or lower, a glycol and water solution must be used instead of water. See section 8.1 for glycol ratio recommendations and proper unit setting.

1.7 MODEL DESIGNATION



- A. The Serial Number identifies the exact configuration of your unit and should be available when contacting the Factory for service or information.
- B. There maybe additional numbers and letters at the end of the model number to indicate additional configuration options on the machine.

Model Designator



Typical placement of the Data tag.
Note: Data tag may be placed elsewhere on certain models.

1.8 COMPONENTS



2.0 INSTALLATION

- 2.1** General
- 2.2** Unit Location
- 2.3** Chilled Water Piping Installation
- 2.4** Air-Cooled Condenser
- 2.5** Make-Up Water Supply Connection
- 2.6** Electrical Connection
- 2.7** Piping installation



2.1 GENERAL

- A. Check the overall condition of the equipment prior to accepting delivery. Check for visible damage and document any evident damage on the delivery receipt. Shipping damage is the responsibility of the carrier.
- B. All process piping materials (such as hose, rigid piping, valves or filters) used in process water piping circuitry must be rated for 100°F minimum temperature and 100 PSI minimum pressure.
- C. All such materials must have the equivalent or larger diameter of the particular process connection that length of process water piping is connected to.
- D. If the chiller is installed in an environment where ambient temperatures could be under 35°F and/or if the unit operating set point will be 48°F or lower, a glycol and water solution must be used instead of water. See section 8.1 for glycol ratio recommendations and proper unit setting.

2.2 UNIT LOCATION

- A. Before placing the unit into position a review of the most suitable location must be made. This unit is designed for outdoor installation.
- B. Factors to consider when selecting a suitable installation location:
 - 1. Provision for adequate ambient air supply to the condenser.
 - 2. Loading capacity of roof or pad.
 - 3. Distance to suitable electrical supply.
 - 4. Accessibility for maintenance.
 - 5. Applicable building codes.
 - 6. Adjacent buildings relative to noise levels.
- C. **Foundation or roof location.** The chiller must be installed on a rigid and level mounting surface with adequate strength to support the operating weight of the chiller including the weight of water and attached piping.
- D. Provision for adequate air supply for condenser:
 - 1. The unit should be located in an area free of foreign material which could clog the condenser air intake. It should be located on a hard level surface, a concrete pad is recommended.
 - 2. All sides of the unit must be a minimum of 4 feet away from any wall or obstruction. Overhead obstructions are not permitted. If enclosed by walls, the unit must be installed as indicated for a unit in a pit.



3. For installation of multiple units, a minimum of 8 feet is required between units placed side by side. If placed end to end a minimum of 4 feet is required between units.
4. Units in pits must have the top of the condenser level with or above the top of the pit and a minimum of 8 feet is required between the unit and the pit walls.
5. Louvers/fences must have a minimum of 80% free area 4 feet minimum clearance between the unit and the lovers/fence. Height of the louver/fence must not exceed the top of the unit.
6. If the chiller is installed in an environment where ambient temperatures could be under 35°F and/or if the unit operating set point will be 48°F or lower, a glycol and water solution must be used instead of water. See section 8.1 for glycol ratio recommendations and proper unit settings.

2.3 CHILLED WATER PIPING INSTALLATION

- A. There are two piping connections on the unit. One is labeled **TO PROCESS**, and the other is labeled **FROM PROCESS**. Refer to typical drawings for recommended piping practices or optional plant layout drawing if supplied.

From Process

This label marks the From Process connection

- B. **FROM PROCESS** : Connect the from process port to the from process supply header.

To Process

This label marks the To Process connection

- C. **TO PROCESS** : Connect the to process port to the process supply header.

- D. Install a high volume basket strainer in the **FROM PROCESS** line with isolation valves. A basket strainer or bag filter with a 20 mesh (400 micron) or finer screen will protect the unit. Installing a filter that is too fine may be unnecessary and may result in frequent filter maintenance.



Typical wye strainer - Not recommended.

A “wye” type strainer is not recommended because it does not have adequate debris holding capacity.

- E. Process water piping should be designed to avoid excessive elbows and/or lengths of pipe or hose. Insulation of these lines is recommended to prevent condensation and capacity losses due to heat absorption.
- F. Valves and filters may be installed in the process water piping to facilitate service and maintenance provided that such devices maintain the full inside diameter of the process connection. If installed, all such devices must be open and clean during unit operation.

2.4 AIR-COOLED CONDENSER

- A. The unit should be located in an area free of foreign material which could clog the condenser air intake. It should be located on a hard level surface, a concrete pad is recommended.

- B. All sides of the unit must be a minimum of 4 feet away from any wall or obstruction. Overhead obstructions are not permitted. If enclosed by walls, the unit must be installed as indicated for a unit in a pit.
- C. For installation of multiple units, a minimum of 8 feet is required between units placed side by side. If placed end to end a minimum of 4 feet is required between units.
- D. Units in pits must have the top of the condenser level with or above the top of the pit and a minimum of 8 feet is required between the unit and the pit walls.
- E. Louvers/fences must have a minimum of 80% free area and 4 feet minimum clearance between the unit and the louvers/fence. Height of the louver/fence must not exceed the top of the unit.
- F. If the chiller is installed in an environment where ambient temperatures could be under 35°F and/or if the unit operating set point will be 48°F or lower, a glycol and water solution must be used instead of water. See section 8.1 for glycol ratio recommendations and proper unit setting.



Typical Process Connections shown on a single zone unit.



Typical Process Connections shown on a dual zone unit.

2.5 Make-up WATER SUPPLY CONNECTION (Optional - in non-freeze Climate applications only)

- A.** The automatic water make-up system continually monitors the reservoir tank and fills it when needed. Connect as follows:
1. Using appropriately rated hose or fluid piping connect the “water make-up” connection to the plant’s water source.
 2. Minimum make-up water supply pressure is normally 20 psi.
 3. Install an owner supplied shut off valve in the make-up water supply line. Install this valve on the outside of the unit.
 4. Use a back flow prevention device as may be required by local codes to prevent possible contamination of potable water.
- B.** Do not use automatic water make-up system when operating with glycol below 48°F or when ambient temperature may be 35°F or lower.

Water Make-up

This label marks the Water Make-up connection



WARNING: Check local codes to determine proper use of back flow prevention device in water make-up supply line.

2.6 ELECTRICAL CONNECTION

A. STANDARD MODELS

1. Units are constructed with a weather resistant electrical enclosure and branch circuit fusing. Electrical power supply requirements are identified on the equipment data plate. Determine the plant’s voltage supply is the same as the unit’s voltage requirements.
2. All electrical wiring must comply with local codes and the National Electric Code.
3. Electrical power supply requirements for standard units are identified on the equipment data tag. Determine that the plant’s voltage supply is the same as the unit’s voltage requirements, taking into account the SSCR Rating.



WARNING: Do not connect the unit to a voltage supply not equal to the unit’s voltage requirements as specified on the unit’s data plate. Use of incorrect voltage will void the unit’s warranty and cause a significant hazard that may result in serious personal injury and unit damage.



WARNING: Electric Shock Hazard. High Voltage is present in the electrical cabinet. Disconnect power before servicing. Follow all facility lock-out tag-out procedures.

4. A customer supplied, four conductor cable is required for connection to a customer supplied fused disconnecting means. The fused disconnecting means shall be sized and installed according to the unit's power supply requirements and local electrical codes. (Some custom units may include a fused or non-fused disconnect switch.)
5. Connect the four conductor power cable to the power entry terminal block on the unit's electrical panel. Then connect the power cable to the fused disconnect switch. There is no power entry hole into the electrical cabinet. This allows the matching of the entry hole size and location to the customer supplied fittings.
6. A unit specific electrical drawing is shipped with the unit.
7. Voltage supplies must be within +/- 10% of the name plate voltage and must be within 2% from leg to leg. Extreme voltage imbalance or using the wrong voltage can damage your chiller and cause premature unit failure as well as a safety risk.
8. A proper ground is required for the unit.



Typical data tag.

B. CONTROL CIRCUIT WIRING


1. The unit's supplied control circuit is 110 volt, 1 phase, 60 cycle.
2. The control circuit is supplied by the factory installed transformer. A control circuit fuse is provided.

C. GENERAL

1. Make certain all ground connections to the unit are properly affixed.
2. Make certain power conductor, disconnecting means, and fusing are properly sized according to the unit's power supply requirements.
3. Follow all local and national codes.
4. Make certain that all owner and factory wire connections are tight before applying power to the unit.




WARNING: Check that all electrical connections are tight before starting. Disconnect power before servicing. Follow all facility lock-out tag-out procedures.



Typical electrical panel show. Refer to the electrical drawing provided for details to the particular unit.

2.7 PIPING INSTALLATION (TYPICAL)



This drawing is supplied to demonstrate a possible piping configuration for the equipment and is general in nature showing pipe sizes and basic routing. It is not intended to be inclusive of every detail required for specific location and installation. Consult with a professional engineer to determine specific needs before installation.

1. Chiller (2 pump outdoor system).
2. Reservoir Drain Connection.
3. Open Drain (can use separate drain or tie into system multi-use drain Item #15).
4. Pump discharge connection (supply To Process).
5. Reservoir Return Connection (From Process).
6. Chilled Water Pipe (To Process, this pipe runs from the outdoor chiller location into the building / process area).
7. Filter (MLS Series In-Line full flow design).
8. Water Inlet Connection (filter).
9. Water Outlet Connection (filter).
10. Bypass Pipe With Valves (redirection of process water flow during filter service).
11. Drain-Back Dam (keeps header pipes full during pump shut down periods).
12. Main Header Valves (closed for header service or during use of alternate source of cooling water).
13. Alternate Source of Cooling Water On/Off Valve (for system emergency back-up).
14. Alternate Water Supply Source (for system emergency back-up).
15. System Multi-Use Open Drain (reservoir overflow, reservoir drain, system emergency back-up).
16. Process Water Drops From Header To Use Point (valved for service shut-off).
17. Pressure Gauge and Thermometer (for system performance monitoring and evaluation).
18. Header Ends Valved and Capped (for future expansion).
19. Header By-Pass Valve (adjustable and pressure activated to maintain flow in header during low process demand).
20. Branch Header Valves (for header service isolation).
21. Branch Header.
22. Valve to Open Drain (for system emergency back-up).
23. Chilled Water Pipe (from process, this pipe runs from the building / process area to the outdoor chiller location).

3.0 OPERATIONS

- 3.1** General
- 3.2** Start Up / Operations Procedure
- 3.3** M1 Control Instrument
- 3.4** LE Control Instrument
- 3.5** MZC Control Instrument
- 3.6** MZC Zone Board
- 3.7** Configuration Switch Adjustment (MZC only)
- 3.8** Controls
- 3.9** Pressure Gauges and Alarm Beacon
- 3.10** Shut Down Procedure



3.1 GENERAL



WARNING: Follow all Factory operations procedures. Failure to do so may create a hazardous operating condition which may result in serious operator injury and/or unit damage.

A. Failure to follow the factory required operations procedure may adversely affect the unit's ability to adequately control process temperature and may create a hazardous operating condition which may result in serious operator injury and/or unit damage.

B. IMPORTANT. If this unit contains a hermetic or semi-hermetic reciprocating compressor it is equipped with a crankcase heater on the compressor. While the compressor is idle, the crankcase heater prevents freon vapor from migrating to and condensing in the compressor crankcase. If freon is allowed to condense in the crankcase, it can be drawn into the cylinders upon start up. This can cause catastrophic damage to the connecting rods, pistons, and valve plates.

To avoid this, **BEFORE THE UNIT IS STARTED, THE POWER SUPPLY SHOULD BE APPLIED TO THE UNIT FOR AT LEAST 12 HOURS, OR UNTIL THE BOTTOM OF THE COMPRESSOR IS WARM TO THE TOUCH.**

If the power has been disconnected more than two hours, the power should be applied for six hours before restarting. Power should be applied to the unit continuously, except for service purposes. The crankcase heater should be checked for proper operation on a regular basis.

C. The OPERATIONS segment of this manual is divided into the following sections:

3.2 Start up/operations - follow this segment to start the unit after the initial installation to the process system or to restart the unit after re-installation to the same or different process system. This section includes information on system fill, electric motor phasing (motor rotation) and process flow adjustments.

3.3 Chiller Control - follow this segment to start up and operate the chiller control. This section includes information on setpoint selection and adjustment, and feature explanations. There are three types of control that can be installed on the OACS unit:


- a. M1 Controller
- b. LE Controller
- c. MZC III Controller

3.4 Shut down procedure - follow this segment to shut down the unit. This segment includes information on system shut down, electrical power supply precautions, and disconnection from system.

3.2 START UP / OPERATION PROCEDURE

A. System Fill

1. For operating temperatures from 48°F to 80°F use water to fill the unit. For operating temperatures below 48°F a water and propylene glycol mixtures must be used. An inhibited propylene glycol can be used for operating temperatures above 48°F if desired to prevent corrosion and scaling. Use the minimum ratio that is recommended by the glycol manufacturer. See section 8 of this manual for more information.
2. The unit has an internal reservoir which must be filled and maintained for proper operation. The unit has a level switch mounted at the proper water level in the reservoir.
3. **WATER QUALITY CONTROL.** Lack of, as well as, improper water treatment can damage the chilling unit. The services of competent water treatment specialist should be obtained and their recommendations followed. It is the equipment owner's responsibility to prevent damage from foreign material or inadequate water treatment. See water treatment section in **section 1.6** of this manual for more information.
4. **FOR AUTOMATIC FILL:** Always install a manual shut off valve on the make-up water supply on the outside of the unit. When electrical power is applied to the unit but the On/Off Selector is in the 'off' position open the owner supplied shut off valve. The level switch will activate the make-up solenoid which will open and the water supply will fill the reservoir tank. **Do not use automatic fill when operating at temperature below 48°F or when ambient temperature may be 35°F or lower.**
5. **MANUAL FILL:** Add fluid directly to the reservoir. When the pump is first started, as process lines are filled and air is purged, additional fluid may be required to restore the reservoir to the correct level. Verify reservoir level via the coolant sight glass.



6. Do not use deionized water in this unit unless your unit was specifically designed for use with deionized water. Consult factory if not certain.

B. PROPER ROTATION (PHASING) OF SCROLL COMPRESSORS & PUMPS & FANS

1. Correct compressor and pump rotation is critical for unit performance and to avoid severe damage to the compressor.
2. All models have their compressor and pump motors factory phased in unison. Therefore, you should only need to check one motor to verify phasing. However, we recommend verifying all motor rotations.
3. After electrical installation the rotation must be checked by observing the pump motor shaft on the end of the pump and comparing its rotation to the directional arrow on the motor.
4. If the rotation needs to be changed it should be done at the main power entry by switching any two power conductors at the terminal block or customer supplied main power disconnect. Recheck rotation before operating the units.
5. Caution must be taken when checking rotation to avoid electrical shock.
6. A scroll compressor may make a loud rattling noise when rotating in the wrong direction.
7. Operating the scroll compressor in the wrong direction will cause the unit to trip on it's internal temperature limit and may cause unit damage. When the temperature limit trips, the compressor must be allowed to cool before it will restart. This many take substantial time.
8. Procedure to set proper rotation:
 - a. Supply electrical power to the unit. Once the correct voltage is supplied to the unit, the control instrument will read "Standby" or "Status Ready". Adjust the setpoint to 70°F or higher to prevent the compressor from activating during this procedure. See Section 3.5 for additional details.



- b. Remove all necessary cover panels to access the pump motor.

- c. Locate the pump's electric motor. The operator must identify the motor shaft inside the electric motor housing. The motor shaft can be seen through the vent slots in the motor housing or by removing the shaft cover.



- d. Depress the Green "I" start button then the Red "O" stop buttons. This will quickly cycle the pump motor.



- e. Remove the shaft cover plug to observe the motor shaft. When the unit is on, the motor shaft will rotate. When switched off, the shaft will slowly "coast" to a stop. As the shaft slows, the operator can identify the rotation of the motor shaft.

Correct rotation (correct phase) is "clockwise", when viewed from the rear of the motor.

Incorrect rotation is "counter-clockwise" (incorrect phase) when viewed from the rear of the motor.

If the shaft does not rotate when the unit is switched on, the operator must identify the cause as outlined in the troubleshooting and repair section of this manual.



Correct shaft rotation is clockwise.

- f. If the motor shaft is phased correctly (shaft turns in a clockwise direction), continue with **step C**. If the motor shaft is **NOT** phased correctly (shaft turns in a counter-clockwise direction), correct as outlined in **step 2**.

2. If the unit is phased **incorrectly**, the operator must:

- a. Disengage the electrical power supply to the unit at the unit's disconnect switch. Follow all facility proper lock-out tag-out procedures before proceeding.
- b. Once the electrical power supply is disengaged the operator can change rotation by switching any two incoming power conductors at the terminal block or customer supplied main power disconnect.

C. PROCESS FLOW ADJUSTMENTS

- 1. The operator must determine and set proper water flow rate for the most efficient and trouble free operation.
 - a. Water flow rate through the process is determined by the pressure losses in the process loop. Generally, higher flow rates result in turbulent flow achieving maximum temperature control and lower maintenance. Since the evaporator in most liquid chillers is flow sensitive, the efficiency of operation is directly related to the flow of liquid.
 - b. Maximum chiller efficiency is obtained at approximately 2.4 gpm per ton of rated capacity. Low liquid flow can reduce efficiency and in some cases allow ice to develop in the evaporator which can damage the

evaporator. Excessive liquid flow will trip the motor overload protection circuit.

2. **Excessive flow will cause the motor to operate at high amperage and eventually open the thermal overload safety shutting off the motor.** Motor amperage rating may be acquired on the motor nameplate.
3. **Low flow may result in poor temperature control and high temperature rises.** To correct this problem, a bypass system must be installed between the to and from process lines. With the bypass valve fully closed, slowly open the valve until the correct motor amperage is achieved. Motor amperage rating may be acquired on the motor nameplate.

D. ADJUSTMENT OF CENTRIFUGAL PUMP. When starting equipment with a centrifugal pump, it is important to properly set the flow rate to prevent overloading of the electric motor. The following example is the start up procedure for a two pump central chiller.

1. Fully open the suction valves to the pumps allowing the pump case to fill with water. Never allow the pump to operate dry, this can cause shaft seal failure.
2. Close the discharge valves. A centrifugal pump can be operated with no flow without damage, although this should not be for an extended period of time. Internal friction will cause the water in the pump case to overheat.
3. Place an amp meter on one leg of the process pump leads at the motor starter block and start the motor. Slowly open the discharge valve allowing the process piping to fill with water. After flow is established, continue to open the discharge valve. The amp draw will increase as the flow increases until you reach the run load amp rating listed on the motor data tag.
4. **Please note:** On initial start up the water use points may not be sufficient to fully load the motor. Recheck the amp draw on the motor and adjust the discharge valve as needed to prevent overloading of the motor as use points are added.
5. Place an amp meter on one leg of the and start the motor. Slowly open the discharge valve allowing the piping to fill with water. After flow is established, continue to open the discharge valve. The amp draw will increase as the flow increases until you reach the run load amp rating listed on the motor data tag.
6. Never operate a pump without water in the case or never operate a pump without checking for proper amp draw.
7. Always operate the pump with the suction valve fully open. Adjust the amp draw with the discharge valve starting from a closed position. Starting from a wide open position can give a false reading and result in motor failure.
8. If during operations the motor overload trips, the overloads will need to be manually reset to restart operations. Once the pump is restarted, check for excessive motor amps at the motor starter block and throttle back the pump's discharge valve as required.




3.3 CG INSTRUMENT OPERATION



CG Series Control. This control instrument is used on units with fixed displacement compressors.


A. INSTRUMENT START-UP

1. When the correct electrical power and adequate water supply pressure are supplied to the unit, it is possible to start the unit.
2. Upon powered up, the instrument displays the Standby Screen.
 - a. **Status : Ready** indicates the unit is ready to start and there are no faults preventing operation.



b. Status : Not Ready.

After applying power a screen that reads “Not Ready” typically indicates the presence of a sensor probe fault, pressure switch fault or motor overload fault. See the troubleshooting and maintenance portions of the manual for additional Information. The fault must be corrected in order to continue operation of the unit.



3. PRECAUTIONS:

The chiller control is programmed from the factory with a setpoint range of 48° to 70°F. To operate below 48°F, the addition of inhibited propylene glycol and modification of the limit control settings are required. These adjustments are done from the chiller controller screen. Diligent monitoring of the water/glycol solution is mandatory to prevent freezing of the evaporator. Freezing may cause the evaporator to rupture allowing water and freon to mix which will cause major damage to the refrigeration system.

R134A and R407C models operating above 70°F and R404A models operating above 60°F require the addition of a refrigerant crankcase pressure regulating (CPR) valve. The CPR valve is necessary to lower the temperature of the gas returning to the compressor so that the compressor is cooled properly. R410A models may be operated up to 80°F without a CPR valve.

Contact your local refrigeration contractor or the factory for further information. The operating range of the chiller control may be changed to 10°F - 90°F by adjusting the Setpoint Lockout (SPL) jumper. Refer to Section 3.3.c.3 of this manual for more information.

4. TO START THE UNIT

- A. Press the Green "I" Button. "Circulating" will appear in the lower portion of the display window. The pump will circulate fluid without engaging the refrigeration system for about 45 seconds. Setpoint and the actual fluid temperature will be displayed as well.



- B. To select setpoint temperature, press and hold the Up or Down Arrow keys until the desired setpoint temperature is displayed in the display window. The default range for the setpoint temperature is 48°F - 70°F or 9° - 21°C.



- C. Press the Home button to view "Outputs", "Suction", "Discharge" and "To Process" values.

Outputs indicate the state of the chiller's refrigerations system. When four small dots are shown the refrigeration system is off. When the first dot is larger, the compressor is operating. For units with digital scroll compressors or fixed scroll compressors and hot gas bypass capacity



control, when the first dot and fourth dot are larger this indicates the compressor is running and the capacity unloading feature is engaged.

Suction indicates the refrigerant suction pressure, sometimes referred to as 'low' or 'evaporator' pressure.



Discharge indicates the refrigerant discharge pressure, sometimes referred to as 'high' or 'head' pressure.



To Process indicates the process cooling fluid (water or water/glycol) pressure.



- D. When the compressor is turned off, the instrument will wait 3 minutes before turning it back on regardless of the To Process temperature or Setpoint.

If a low pressure or optional low flow fault has occurred, the control will attempt to turn the compressor back on after 3 minutes. If the fault condition remains, the compressor will not restart and the control will retry after 1 minute. The sequence will repeat 3 times then the system will lock-out and the unit must be powered off/on to restart the unit.

If a high pressure fault occurs the fault must be acknowledged by pressing the start button before the system will attempt to restart.

- E. Under normal conditions (no fault conditions, compressor has been off for 3 minutes) the instrument will turn on the compressor when the To Process temperature is above the Setpoint. The instrument will engage the capacity control system (digital unloading or hot gas bypass) when the To Process temperature is below the Setpoint by no more than 3 degrees. Units equipped with a digital scroll compressor (includes a “D” in the model number such as CGD-10A) will operate in the unloaded state for a maximum of 50 seconds out of every 60 seconds.

The instrument will turn off the compressor and capacity control system when the To Process temperature is 4 degrees or more below the setpoint.

3.4 INSTRUMENT : MAIN MENU

- A. The Main Menu offers the ability to set and change values in the following areas:

1. Setpoints
2. Utilities
3. Network
4. Flow
5. Options
6. Machine

- B. The Main Menu is accessible from the Standby screen by pressing the Select button.



- C. The Main Menu is also accessible from any Operating screen by pressing the Select button. In the example below, while on the Cooling screen, pressing the Select button will advance to the Main Menu.




3.5 INSTRUMENT : SETPOINTS MENU

- A. Under the Setpoints menu item, the values for the Process Setpoint, Hi Deviation, Low Deviation and Low Flow can be set or changed. Digital flow rate display is an option and may not be included on your machine.
- B. **Process Setpoint.** Use the Up or Down buttons to change the process setpoint.



1. The Setpoint range is from 48°F to 70°F.



2. Once acknowledged, the unit will control to the new setpoint temperature. Press the Back button repeatedly to return to the Setpoints screen or press the home button to return to the Home screen.

C. **Hi Deviation.** The High Deviation value programs the controller to sound the alarm if the process temperature exceeds the set difference from setpoint. For example, Hi Deviation = 10°F, Setpoint = 50°F. Hi deviation alarm will sound if the temperature reaches 60°F.



1. The factory default is 10°. The range for the Hi Deviation is from 0°F - 50°F.

2. Once acknowledged, press the Back button repeatedly to return to the Setpoints screen or press the home button to return to the Home screen.

D. **Lo Deviation.** The Lo Deviation value programs the controller to sound the alarm if the process temperature exceeds the set difference from setpoint. For example, Lo Deviation = 10°F, Setpoint = 50°F. Lo deviation alarm will sound if the temperature cools to 40°F.




1. The factory default is 10°. The range for the Lo Deviation is from 0°F - 50°F.

2. Once acknowledged, press the Back button repeatedly to return to the Setpoints screen or press the home button to return to the Home screen.

- D. Low Flow (optional feature not included on all units).** The Low Flow value programs the controller to sound an alarm if the process flow goes below the low flow set value. For example, if the flow set value is 3 GPM and if the flow goes below 3 GPM an alarm condition is indicated. Note: the low flow alarm feature is only available with the purchase of the optional flow meter.

- The factory default is 0 GPM. The range for the Low Flow is from 0 to 100 GPM.



- Once acknowledged, press the Back button repeatedly to return to the Setpoints screen or press the home button to return to the Home screen.

3.6 INSTRUMENT : UTILITIES MENU

- A.** Items in the Utilities menu include the operations for the Software Version, Display Test and Sensor Display.



- B. Software Version.** The software version number is the current version of the controller's software. This number can be useful when troubleshooting at times.



- Select the Software Version item from the Utilities Menu to advance to the software version screen.
- Press the Back button to return to the Utilities menu.

- C. Display Test.** The Display Test will test the entire for bad pixels or sectors.




- Select the Display Test item from the Utilities Menu to advance to the Display

Test screen.

2. The test will show a blank screen. If any bad pixels or sectors are detected, those pixels or sectors will be dark. If dark pixels or sectors are indicated, contact the factory repair or replacement options.

D. Sensor Display. There are up to 11 sensors the controller monitors.

1. Select the Sensor Display item from the Utilities Menu to advance to the first Sensor Display screen.




2. Scrolling through the Sensor Display reveals data for the sensor.

- To Process ... displayed in Fahrenheit and Celsius
- From Process ... displayed in Fahrenheit and Celsius
- Process Probe Temperature ... displayed in Fahrenheit and Celsius (optional)
- MCU Temperature ... displayed in Fahrenheit and Celsius
- Head Pressure ... displayed in PSI and kPa
- Suction Pressure ... displayed in PSI and kPa
- Process Probe Pressure ... displayed in PSI and kPa
- Board Temperature ... displayed in Fahrenheit and Celsius
- Flow ... display in GPM and dl/min (optional)
- Flow Switch ... indicates on or off (optional)
- Water Make-Up Switch ... indicates on or off (optional)

3.7 INSTRUMENT : NETWORK MENU

A. Items in the Network menu include Protocol, Address and Baud Rate




- B. Protocol:** This is the data format for communication between the unit and the host computer. Available values are SPI CCP, Modbus RTU and CAMAC. SPI is the standard Society of Plastics Industry, Inc. protocol. CAC is the CAMAC protocol used on older

Milacron machines. Modbus RTU is used in serial communication and is a common serial communications protocol for industrial equipment.



1. Press the Select button to select Protocol.
2. Use the Up or Down arrow buttons to select the preferred protocol.
3. Use the Select button to save the selection and confirm success.

C. Baud Rate: This is the data transfer rate between the unit and the host computer.



1. Press the Select button to select Baud Rate.
2. Use the Up or Down arrow buttons to select the baud rate. The available rate units are 1200, 2400, 9600, 19200 and 38400.
3. Press the Select button to save the selection and confirm success.


D. Address: This is the number assigned to the unit in a network.




1. Press the Select button to select Address.
2. Use the Up and Down arrow keys to select the address for this unit. The factory default is 1. The selection range is from 1 - 10.
3. Press the Select button to save the address and confirm success.

3.8 INSTRUMENT : FLOW MENU (Option)

- A. The Flow Menu is only functional when the optional flow meter is installed. Items in the Flow Menu are Enable, Offset and Calibration.



B. Advance to the Flow Enable / Disable screen. Select Enabled to enable the flow option.



C. Offset. This allows the user to select the flow offset according to the pump horsepower.



1. These values should be factory set and should not be changed. Adjust only if they are set to values other than the factory default.

D. Calibration. This allows the user to calibrate the unit's flow meter.




1. Using a reliable and accurate external flow meter the user can input a calibration constant value in the screen so that the unit flow display matches the external flow meter.

2. Use the Up or Down arrow keys to input the value and then press the Select button to save and confirm success.


3.9 INSTRUMENT : OPTIONS MENU

A. The single selection under the Options menu is the Remote Start.



B. Please note: this option requires factory or field installation of optional equipment.

1. Select Remote Start from the Options menu.




2. Advance to the Remote Start Enable / Disable screen. Select Enabled to enable the remote start feature. Select Disabled to disable the feature.


3. Once acknowledged, press the Back button repeatedly to return to the Options screen or press the home button to return to the Home screen.

3.10 INSTRUMENT : MACHINE MENU

A. The Machine Menu allows the units to set values for these items :




B. Set Date :



1. Set the date by selecting the Set Date option from the Machine Menu. Using the Up and Down Arrow keys to select the month, day and year. Use the Select and Back Buttons to advance between Month, Day and Year.

C. Set Time :

1. Set the time by selecting the Set Time option from the Machine Menu. Using the Up and Down Arrow keys to select the hour, minute and seconds. Use the Select and Back Buttons to advance between Hour, Minute and Seconds.



D. Minimum Setpoint. This parameter sets the lowest permissible setpoint temperature. The factory default is 48°F. The range is from 20°F - 80°F.


- 1. For Minimum Setpoints below 48°F.** A warning is displayed when a minimum setpoint below 48°F is entered. The warning ensures the operator is aware the an appropriate mixture of water/glycol is circulating to prevent freezing.



- 2.** After a minimum setpoint below 48°F is selected, a caution display will appear when reducing the operating setpoint below 48°F. The warning must be acknowledged before the change is made by pressing the Select button.



- 3. For Minimum Setpoints 48°F and above.** From the Machine Menu, advance to the Minimum Setpoint screen to enter the minimum setpoint. Confirm the selection with the Select Button.




E. Hi Temp Shutdown. This shuts down the unit if process temperature exceeds the selected value to prevent excessively warm fluid temperature.



1. From the Machine Menu, select Hi Temp Shutdown via the Up or Down Arrow keys. Adjust the temperature as desired. Select button to save and confirm success.
2. The factory default value is 100°F. The range is from 70°F - 100°F.

F. Units. This screen controls how the temperature is displayed. The options are English (°F) or Metric(°C). Also, when the optional flow meter is installed, the flow will display in GPM if English is selected or LPM if Metric is selected.



1. Use the Up or Down arrow keys to select the Unit display and then press the Select button to save and confirm success.
2. The factory default value is English.

G. Pressure and Timer Screens. These parameters are factory set and should not be adjusted without consulting the factory. Changes are recorded in the instrument memory and adjusting these parameters could void the Factory warranty.

Pressure Related :

- LP Cut Out
- LP Cut In
- HP Cut Out

Timer Related :

- LP Start Up Delay
- LP Run Delay

H. Unit Screens. These parameters are factory set and should not be adjusted without consulting the factory. Changes are recorded in the instrument memory and adjusting these parameters could void the Factory warranty.

- Secondary Pump
- Chiller Type
- Cooling Source

3.11 CONTROLS

- A. **Flow switch:** Installed on each evaporator water circuit. Its mission is to monitor the fluid flow and to shut down the compressor in case a harmful low flow condition should develop.
- B. **Freezestat:** Factory adjusted to turn off the compressor in the event an unsafe temperature should exist from the evaporator. This switch should be periodically checked for proper operation.
- C. **High Pressure:** Factory set or fixed cut out. Digitally set and monitored on the control instrument
- D. **Low Pressure:** Factory or fixed cut out and cut-in points based on refrigeration type, automatic reset. Digitally set and monitored on the control instrument

NEVER LOWER THE CUT OUT SETTING WITHOUT ADDING GLYCOL TO THE CIRCULATING SYSTEM. EVAPORATOR DAMAGE WILL RESULT AND WILL NOT BE COVERED BY THE WARRANTY.

- E. **Oil pressure safety switch** de-energizes the compressor if oil pressure in the compressor is not adequate. Refer to the troubleshooting guide for common reasons for this failure. (Provided on certain models.)
- F. The **alarm pressure switch** functions to energize the alarm if coolant pressure is denied the process.

3.12 PRESSURE GAUGES & OPTIONAL ALARM BEACON

- A. The **to process pressure** gauge indicates fluid pressure being delivered by the process pump to the load and is digital monitored on the control instrument.
- B. The **refrigerant head pressure** gauge indicates the pressure of the refrigerant as it is being condensed in the condenser and is digitally monitored on the control instrument.
- C. The **refrigerant low pressure** gauge indicates the compressor suction pressure, and is directly related to the temperature setting on the temperature control and is digitally monitored on the control instrument.
- D. The optional **alarm beacon** is visual and audible. The alarm will activate when the water temperature leaving the chiller is too high and when fluid pressure is lost from the process pump. An alarm silence switch is provided to deactivate the alarm while corrective measures are being taken.



3.13 UNIT SHUT DOWN/DISCONNECT SEQUENCE

A. PRECAUTIONS/WARNINGS

1. The operator must precisely follow all shut down procedures outlined in this manual. If the operator fails to follow precisely all procedures outlined in this manual, an unsafe condition can develop resulting in damage to the unit or personal injury.

B. UNIT SHUT DOWN

1. To shut down the unit without disconnecting from the process:
 - a. Turn off the unit..
 - b. Maintain electrical power to the unit at all times except for service purposes.
2. To shut down the unit and disconnect from the process:
 - a. Turn off the unit.
 - b. Disengage the electrical supply to the chiller at the disconnecting device.
 - c. Disconnect all process lines.



WARNING: Follow all shut down procedures outlined in this manual.



WARNING: Relieve static pressure before disconnection process lines.

4.0 TROUBLESHOOTING

- 4.1** Unit Will Not Start
- 4.2** Compressor Hums But Will Not Start
- 4.3** Shuts Off On High Pressure
- 4.4** Shuts Off On Low Pressure
- 4.5** Compressor Shuts Off On Internal Overload
- 4.6** Low or No Process Pressure or Water Flow
- 4.7** Cooling Capacity Inadequate
- 4.8** Sensor
- 4.9** Coolant Pumps
- 4.10** Chiller Controller
- 4.11** Replacement Control Configuration





WARNING: Before troubleshooting or servicing this unit, follow all company lock-out tag-out procedures.

4.1 UNIT WILL NOT START

- A. **Power off.** Check main disconnect.
- B. **Main line open.** Check fuses.
- C. **Loose terminals.** Tighten terminals with POWER OFF.
- D. **Control circuit open.** Check control voltage fuses and transformer.

4.2 COMPRESSOR HUMS BUT WILL NOT START

- A. **Contactor problem.** Check contacts and contactor operation.
- B. **Low voltage.** Check voltage at main and at the unit. If voltage is OK at the main but low at the unit, increase wire size. If low at main, consult your local power company. Voltage must be +/- 10% nameplate rating.
- C. **No power on one phase of a three phase unit.** Check fuses in control panel and main disconnect. Also check unit wiring, main plant fuse and wiring. If the problem is with the main power supply coming into the plant, call the local power company.
- D. **Loose terminals.** Power off and follow all company lock-out tag-out procedure before tightening terminals.

4.3 SHUTS OFF ON HIGH PRESSURE LIMIT

Note: Units may be equipped with either an adjustable or non-adjustable “fixed” high pressure switch. If the refrigerant pressure exceeds the setting of the adjustable switch it must be manually reset when the discharge pressure falls to a safe level. The non-adjustable “fixed” high pressure switch will automatically reset when the discharge pressure falls to a safe level.

- A. **Insufficient condenser air flow.** Check condenser filter for dirt, fins may be plugged with dirt or foreign material. Also, check for proper fan rotation.

Note: All enclosure panels on the air-cooled condenser must be attached.

- B. **Fan motor not operating.** Have electrician check fuses and wiring, motor starter and overloads, and motor. Repair or replace motor if defective.
- C. **Improperly set high pressure control.** Have refrigeration serviceman reset or replace the control if defective.



Adjustable High Pressure Switch



Fixed High Pressure Switch

4.4 SHUTS OFF ON LOW PRESSURE CONTROL

Note: Units may be equipped with either an adjustable or non-adjustable “fixed” low pressure switch. The adjustable or fixed low pressure switch will automatically resets when the pressure rises above the cut-in pressure. If this does not occur contact the Manufacturer’s service department for instructions.

Note: If your chiller is equipped with the Advantage M1 control instrument see section 3.3.D.3 for additional specific information on how the M1 control instrument handles a low refrigerant pressure fault.

If the unit low pressure limit activated three (3) consecutive times during start-up the unit will lock out and will not be allowed to start. To restart, the unit must be powered down and back on.

*See Temperature-Pressure chart in Section 8.2 for refrigerant pressure.

The low pressure switch is set to cut-out at 32°F and cut-in at 36°F - 39°F*. If a low pressure condition exists for more than five seconds the compressor will stop and a “L-P” fault will appear in the display window.

After the refrigerant pressure rises above the cut-in pressure, a three minute time delay will occur before the compressor restarts. This will protect the evaporator and compressor from damage should a problem occur in the refrigeration system or if the chiller is operated under circumstances which could cause damage to the refrigeration system.



Adjustable Low Pressure Switch



Fixed Low Pressure Switch

- A. Low or no water flow through the evaporator.** Adjust the flow per sections 3.2.C and 3.2.D.
- B. Head pressure too low.** Check that entering air temperature is above 60°F. If below 60°F, find out reason why.
- C. Low refrigerant charge.** Check for adequate refrigerant charge (bubbles or misty sight glass indicates low charge). If charge is low, have system checked for leaks and recharged by a refrigeration serviceman.
- D. Improperly set low pressure switch.** Have a refrigeration serviceman reset control or replace if defective.
- E. Restriction in the liquid line.**
 - 1. Clogged filter drier.** Check for pressure or temperature drop and have drier core replaced by a refrigeration serviceman.
 - 2. Liquid line valve or suction valve on compressor is partially closed.** Open fully.
 - 3. Liquid line solenoid not opening fully or leaking during off cycle.** Have the solenoid repaired or replaced if defective by a refrigeration serviceman.
 - 4. Expansion valve plugged or inoperative.** Check thermal bulb and capillary

tube for damage. Have repaired or replaced if defective by a refrigeration service man.

4.5 COMPRESSOR SHUTS OFF ON INTERNAL OVERLOAD

- A. **Control does not reset.** Have compressor windings and internal solid state safety control checked by a refrigeration serviceman. Have it repaired or replace if defective.

4.6 LOW OR NO PROCESS PRESSURE OR WATER FLOW

- A. **Valves.** Check if water valves are open.
- B. **Pump.** Check pump for correct rotation. Check pump suction for restriction. Replace motor if defective.
- C. **Filters.** Check filter in the chilled water circuit and clean if necessary.
- D. **Pressure switch (or flow switch).** Readjust or replace if defective.
- E. **Fuses and wiring.** Have electrician check the fuses and wiring.

4.7 COOLING CAPACITY INADEQUATE

- A. **Low refrigerant charge.** Check for adequate refrigerant charge (bubbles or misty sight glass indicates low charge). If charge is low, have system checked for leaks and recharged by a refrigeration serviceman.
- B. **Hot-gas bypass valve stuck open.** Have repaired or replace if defective by a refrigeration serviceman.
- C. **Expansion valve plugged or inoperative.** Check thermal bulb and capillary tube for damage. Have repaired or replaced if defective by a refrigeration serviceman.
- D. **Plugged filter.** Check filter in chilled water circuit and clean.
- E. **Air in system.** Purge air.

4.8 SENSOR

- A. The sensor is a solid state temperature transducer which converts temperature input to proportional current output.
- B. To quickly test for a defective probe, switch connections between the defective probe and a probe known to be working properly. A defective sensor will display a "---" in the display window on the instrument control. Please note that "---" will also display when process temperatures are above 100°F.



Typical chilled water sensor probe with 2 pole connector.

4.9 COOLANT PUMP (process, evaporator and standby)

- A. The centrifugal pump is designed to operate at a specific flow and pressure at the maximum run load amp draw of the motor. Too much flow can overload the motor and cause the overload circuit to open and stop the pump.
- B. If the overload trips, check for electrical shorts, loose wires, or blown fuses. If these check OK, reset the overload circuit and restart the chiller.

4.10 CHILLER CONTROLLER

- A. The control instrument is used for all normal set ups, diagnostics, temperature readout and operational information. It contains the software and electronic components which operate the control instrument.
- B. The control instrument is not field repairable. It can be easily removed and replaced or repaired if a problem occurs.
- C. All control instruments used in Advantage water chillers are covered by the machine's warranty. Proprietary "tailor made" instrument are manufactured specifically for Advantage by our affiliated company Advantage Electronics.

If you experience problems with your Advantage control instrument, it's as easy as 1-2-3 to execute our repair or replacement system in order to get your Advantage equipment running.

D. IN WARRANTY SERVICE INCIDENT

- 1. Call the Manufacturer Service Department for diagnostic assistance.
- 2. If a control instrument is determined to be at fault, a new or reconditioned instrument will be sent as a replacement.
- 3. Return the defective instrument freight pre-paid for a full credit. If the faulty instrument is not returned you will need to pay for it.

E. OUT-OF-WARRANTY SERVICE INCIDENT

- 1. Call the Manufacturer Service Department for diagnostic assistance.
- 2. If a control instrument is determined to be at fault, you have 3 options:
 - a. Purchase a new instrument as a replacement.
 - b. Send your instrument back for repair, freight prepaid. For a nominal fee (contact factory for current fees) your instrument will be repaired and returned.
 - c. Purchase a new instrument and repair the old one as a back up.



3. If you are sending your instrument back for repair do not disassemble the instrument.


F. OTHER INFORMATION

1. Repair Warranty: 1 year.
2. **Ship to Manufacturer.**
3. Include in box: part, purchase order, contact name, phone number, symptom (if available).
4. For Priority Service, send the instrument to us via overnight shipment. We usually repair these instruments the same day we receive them!



4.11 REPLACEMENT INSTRUMENT CONFIGURATION

- A. A replacement instrument must be configured properly to operate as intended. Failure to configure the instrument can result in poor unit performance and may damage the chiller.
- B. The list below provides the current available configuration settings for the MG instrument. Prior to operating the chiller after an instrument replacement, the instrument must be configured to the proper setting per the attached list. Contact the Advantage service department for assistance in determining the proper configuration for your chiller. 317-887-0729
- C. To check the configuration, follow these steps.
 1. Prepare unit with power applied to unit but not operating.
 2. On the MG control instrument, press 'Machine'.



3. Press 'Chiller Type'. The current configuration is highlighted by arrows.
4. If the configuration is correct, no further action is required.

5. If the configuration is not correct:
 - a. Use the Up and Down Arrow buttons to select the correct Chiller Type. See the chart below for available chiller configurations.

MG Chiller - Chiller Type Configuration

Number	MG Display	Chiller Type	Output Summary	Chiller Type	Output 1	Output 2	Output 3	Output 4
1	1C + 1HG [CENT]	1 Compressor, 1 Hot Gas Bypass		Central	Compressor	XXX	XXX	Hot Gas Bypass
2	1C + 1HG [PORT]	1 Compressor, 1 Hot Gas Bypass		Portable	Compressor	XXX	XXX	Hot Gas Bypass
3	1C + 1UL + 1HG [CENT]	1 Compressor, 1 Unloader, 1 Hot Gas Bypass		Central	Compressor	Unloader	XXX	Hot Gas Bypass
4	1C + 2UL + 1HG [CENT]	1 Compressor, 2 Unloaders, 1 Hot Gas Bypass		Central	Compressor	Unloader	Unloader	Hot Gas Bypass
5	1C + 1UL [CENT]	1 Compressor, 1 Unloader		Central	Compressor	Unloader	XXX	XXX
6	1C + 2UL [CENT]	1 Compressor, 2 Unloaders		Central	Compressor	Unloader	Unloader	XXX
7	2C + 1HG [CENT]	2 Compressors, 1 Hot Gas Bypass		Central	Compressor	Compressor	XXX	Hot Gas Bypass
8	2C + 1HG [PORT]	2 Compressors, 1 Hot Gas Bypass		Portable	Compressor	Compressor	XXX	Hot Gas Bypass
9	Screw + 3L [CENT]	1 Screw Compressor w/ Pulse		Central	Compressor	50% Capacity	75% Capacity	Pulse
10	Screw + 2L [CENT]	1 Screw Compressor w/o Pulse		Central	Screw Compressor	50% Capacity	75% Capacity	XXX
11	1DIG [CENT]	1 Digital Scroll		Central	Digital Scroll Compressor	XXX	XXX	XXX
12	1DIG [PORT]	1 Digital Scroll		Portable	Digital Scroll Compressor	XXX	XXX	XXX
13	1DIG + 1C [CENT]	1 Digital Scroll Compressor, 1 Compressor		Central	Digital Scroll Compressor	Compressor	XXX	XXX
14	1DIG + 1C [PORT]	1 Digital Scroll Compressor, 1 Compressor		Portable	Digital Scroll Compressor	Compressor	XXX	XXX

- b. Use the Right Arrow button to make the selection. A Change Setting Chiller Type screen will appear.
 - c. Use the Left or Right Arrow buttons to acknowledge the selection and return to the Home Screen.
7. Once configured correctly the unit is ready to operate.



5.0 MAINTENANCE

- 5.1** Warranty Service Procedure
- 5.2** Periodic Preventative Maintenance
- 5.3** Special Maintenance
- 5.4** Solenoid Valve Service
- 5.5** Pump Seal Service
- 5.6** Checking The Refrigerant Charge
- 5.7** Proper Cleaning Procedure for Brazed Plate Evaporators
- 5.8** Configuration Switch Adjustment (MZC Instruments Only)



5.1 WARRANTY SERVICE PROCEDURE

- A. In the event of a problem with a chiller that can not be resolved by normal troubleshooting procedures, the customer is invited to consult the Service Department for assistance. The correct model number and serial number of the chiller must be available. The service department will attempt to isolate the problem and advise repair procedures. Often times, with the customer's input and with the machine diagnostics, problems can be determined with "over-the-phone" consultation.
- B. If the problem is beyond the scope of "over-the-phone" consultation, and if the warranty status of the machine is valid, the Manufacturer will contact the nearest authorized service contractor and provide authorization to conduct an "on-site" inspection of the unit in order to determine the course of repair. If the chiller is not covered by the warranty, the Manufacturer will advise on the repair and recommend available service contractors.
- C. It is of the utmost importance that you provide the correct model number and serial number of the machine in question. This will allow the Service Department to obtain the correct manufacturing records which will help to properly troubleshoot the problem and obtain the proper replacement parts when they are required. This information is stamped on the data tag that is attached to the electrical enclosure of each machine.
- D. The Service Department must be notified prior to any repair or service of a warranty nature. Warranty claims will not be honored without prior authorization.

5.2 PERIODIC PREVENTATIVE MAINTENANCE

- A. Lubricate all motors. Note that some motors are supplied with sealed bearings.
- B. Tighten all wire terminals.
- C. Clean and check motor starter and contactor contacts.
- D. Check safety switch settings.
- E. Clean condenser fins of dust and dirt (air cooled models only).
- F. Back flush evaporator.
- G. Check glycol/water solution ratio for operating temperature.
- H. Check system for leaks.
- I. Refrigerant sight glass: Check for bubbles when compressor is operating at 100%. Check the moisture indicator for a color other than green.
- J. Clean unit.



5.3 SPECIAL MAINTENANCE

- A.** Any service of the refrigeration system must be accomplished by a certified refrigeration technician.
1. Addition of compressor oil.
 2. Addition of refrigerant.
 3. Repair of a refrigerant leak.
 4. Adjustment of super heat.
 5. Changing of filter-drier or drier core.
 6. Repair of a refrigeration solenoid.



5.4 Optional AUTOMATIC WATER MAKE-UP SYSTEM service (Only units in no freeze climates)

- A.** The automatic water make-up system consists of a level switch and a solenoid valve (figure 5.4B). When the tank level is low the level switch signals the solenoid valve to open allowing make-up water to re-fill the tank.
- B.** Level switch maintenance and service.
1. The level switch contacts engage and disengage the water make-up solenoid valve.



Typical water make-up level switch



2. Poor water quality can allow debris or a film build-up on the level switch contacts which can impair operation. Clean the contacts on a regular basis. If cleaning the contacts does not remedy the problem the level switch must be replaced.

C. Make-up solenoid valve service.

1. The make-up solenoid valve may require service for a failed coil or more often it will not fully close because debris from poor make-up water quality is in the valve mechanism.
2. To replace the coil, disengage power from the unit following all lock-out tag-out procedures. Remove the wires from the failed coil and remove the coil from the valve stem. Install the new coil on the stem and reconnect the wires.
3. To service the solenoid valve follow the procedure below.
 - a. Disengage process operations according to the procedure outlined in this manual. Be certain process fluid pressure is relieved (coolant pressure gauge reads "0") and water system flow is shut off.
 - b. Disengage main power supply. The operator must follow all lockout/tagout procedures.
 - c. Remove or open any access cover panel and set aside to gain access to the make-up solenoid valve.
 - d. The solenoid valve can be disassemble by removing the 4 retaining screws.
 - e. Keeping all electrical connections intact, lift the coil and top solenoid base assembly and set aside.
 - f. **Note the arrangement of the core spring and core assembly, diaphragm spring and diaphragm assembly. (See diagram.)**
 - g. Clean all components as required.



Typical water make-up solenoid valve



5.5 PUMP SEAL SERVICE

A. The coolant pump seal is a carbon/niresist shaft seal assembly including a stationary member, rotating member and tension spring (figure 5.5A).

B. The operator can determine the pump seal is leaking when fluid is identified leaking from the pump case adapter. Generally, a pump seal will leak due to inadequate unit pressure, excessive flow and poor fluid quality.

C. The operator should follow this procedure to replace the pump seal:

1. Disengage process operations according to the procedure outlined in **section 3.4**. The operator must be certain process fluid temperature is under 100°F and pressure is relieved (COOLANT pressure gauge reads "0") and water make-up flow is shut off and all pressure relieved.
2. Disengage main power supply. The operator must verify the proper lockout procedures are followed.
3. Access the pump motor by opening or removing any cover panels as necessary (figure 5.5B).
4. Drain machine. The machine can be drained by using the drain valve located on the pump case. Drain fluid into a suitable container for reuse or disposal according to manufacturer's instructions (if a glycol solution is used).
5. Locate and remove the three motor wire leads from the motor wiring terminals. The operator should "map" the wire terminal locations to ensure correct rewiring. The power cord should be removed from the motor housing (figure 5.5C).
6. Locate and remove the pump casing bolts. These bolts secure the motor and motor adapter to the pump casing (figure 5.5D).





Figure 5.5A



Pump motor

Figure 5.5B



Pump motor


Figure 5.5C



Typical pump casing bolt


Figure 5.5D

7. Separate the motor and motor adapter from the pump casing to expose the pump impeller (figure 5.5E). Remove the motor and motor adapter from the unit and place on a workbench to continue the procedure.
8. Locate and remove the dust cap from motor end to expose slotted motor shaft. The motor shaft is free to rotate, but must be secured to remove the impeller. To secure the motor shaft, insert a flat bladed screw driver in slot to hold the shaft stationary (Figure 5.5F).
9. Locate and remove impeller locking screw (Figure 5.5G). Using a socket and ratchet, the impeller retaining screw can be removed. Once the retaining screw is removed, the impeller can be “unthreaded” from the motor shaft to expose the pump seal assembly.
10. Remove all seal parts (Figure 5.5H). Note seal component arrangement to facilitate reassembly.
11. Clean motor shaft and lubricate with a mild soap solution.
12. Install new stationary seal member in pump casing cavity (figure 5.5I). The operator must be certain the stationary seal member is fully squared and seated in cavity.
13. Slide the rotating member onto lubricated pump shaft (figure 5.5J). The operator must be certain not to damage or tear rubber bellows assembly.
14. Place the spring onto the rotating member.
15. Align the impeller, spring and rotating member before reinstalling the impeller (figure 5.5K). The operator must be certain the spring and rotating member are aligned before the impeller is fully tighten and the impeller retaining screw is reinstalled.



Impeller

Figure 5.5E



Motor shaft

Figure 5.5F



Typical impeller

Figure 5.5G



Seal components

Figure 5.5H

16. Clean pump casing, cavities, impeller and O-ring before reassembly.
 17. Mate the motor and motor adapter to the pump casing. Reinstall the pump casing bolts.
 18. Reconnect the motor power cord and leads.
 19. Restore all cover panels as were removed.
- E. When the pump seal replacement procedure is complete, the operator may restart the unit according the **section 3**.



Stationary member Figure 5.5I




Stationary member Figure 5.5J



Seal members Figure 5.5K

5.6 CHECKING THE REFRIGERANT CHARGE

- A. All standard chillers are manufactured with thermostatic expansion valves as the metering device to the evaporator.
- B. All standard chillers have a refrigerant sight glass with a moisture indicator. To check the refrigerant charge under normal operating conditions:
 1. Remove the plastic cap covering the sight glass.
 2. Start the chiller and allow system pressures and temperatures to stabilize.
 3. With the unit operating at 100% capacity (not in the “capacity control” mode) the sight glass should appear clear with no foam or bubbles evident. If foam or bubbles are evident, the chiller has suffered from a loss of refrigerant and should be checked by a qualified refrigeration technician.
 4. The “dot” in the middle of the sight glass is the moisture indicator. It should appear green at all times. A white or yellow color indicates moisture has invaded the refrigeration system, which is detrimental to the life of the compressor. The filter-drier should be replaced by a qualified refrigeration technician.



Refrigerant Sight Glass

5.7 PROPER CLEANING PROCEDURE FOR BRAZED PLATE EVAPORATORS


- A. The brazed plate evaporator is made of stamped stainless steel plates, furnace brazed together with copper based joints. The complex geometry of the flow passages promotes turbulent flow which gives high efficiency and reduces fouling by mineral deposits. Large solids such as plastic pellets or chunks of mineral deposits will collect at the water inlet port at the evaporator and restrict flow through some of the passages. If this possibility exists, the Manufacturer recommends filters or strainers be added to the “from process” line. If the evaporator becomes fouled there are a couple of methods for cleaning.
- B. To begin, remove the piping to the “water in” port at the evaporator. Remove any solids that have collected at this point. Then back flush the evaporator to remove any solids that may be trapped between the plates (see back flush procedure below). If there are mineral deposits adhered to the plates, the evaporator must be back flushed with a mild acid solution (5% phosphoric or 5% oxalic acid is recommended.) After cleaning rinse with clear water before returning to service. Continue with step C on the next page.
- C. **Back flushing procedure:**
 1. Turn off all power to the machine. For chillers with a reservoir tank, drain the tank



Brazed Plate Evaporator

to below the evaporator outlet. For chillers without a reservoir tank, drain total unit.

2. Connect a water supply hose to the evaporator water outlet. If acid cleaning, connect the discharge hose from the acid pump to the evaporator outlet port.
3. Connect a hose to the evaporator water supply port and to an appropriate containment vessel. If acid cleaning, connect the evaporator water inlet port to an acid solution reservoir tank. Dispose of all back flush fluid according to local codes.
4. The cleaning fluid source should have at least 20 psi available. If acid cleaning, follow the instructions supplied with the acid solution carefully.
5. When the procedure is complete, reinstall all water lines to original factory orientation. Restart the unit and check for proper operation.
6. **Note:** This procedure is not normal maintenance. Maintaining proper water quality and filtration will minimize the need to back flush the evaporator.



6.0 COMPONENTS

6.1 Refrigerant System

6.2 Coolant system



6.1 REFRIGERATION SYSTEM

A. COMPRESSOR: Hermetic or semi-hermetic compressors take low pressure/low temperature refrigerant gas and compress the gas into high pressure/high temperature gas.

B. AIR-COOLED CONDENSER: The air cooled condenser removes BTU's from the compressed refrigerant gas. The action causes the gas to "condense" into a liquid state still under high pressure. Air flow across the condenser is achieved via a motor driven fan assembly. The air-cooled condenser is located outdoors on most Titan central chillers. Models using air-cooled condensers are designated with a TI-A in the model number.



Compressors. Configuration may be different on specific units.

C. FILTER-DRIER: The filter-drier removes contaminants and moisture from the liquid refrigerant.

D. LIQUID LINE SOLENOID VALVE: Controlled by the instrument, this valve closes when the compressor cycles off to prevent refrigerant liquid from migrating to the evaporator. The valve opens when the compressor cycles on.



Air-cooled condenser. Typical unit shown.

E. REFRIGERANT SIGHT GLASS: The refrigerant sight glass indicates refrigerant charge and moisture content. Refrigerant charge is determined by a clear liquid flow. Bubbles indicate low refrigerant. Moisture content is indicated by the color of the element. Element color is normally green. If the color of the element is chartreuse or yellow, the system has been contaminated with moisture. In such case, the filter-drier must be replaced. The replacement of the filter-drier must be completed by a qualified refrigerant service technician.

F. EXPANSION VALVE: The expansion valve throttles flow of refrigerant liquid into the evaporator and creates a pressure drop in the refrigerant system that allows the liquid refrigerant to "boil off" inside the evaporator.

G. EVAPORATOR: The evaporator is a brazed plate heat exchanger where the refrigerant liquid is allowed to evaporate (boil off) to absorb heat (BTU) from the process fluid. As the heat is absorbed, the process fluid is chilled.

H. HOT GAS BY-PASS SOLENOID: The hot gas by-pass solenoid prevents short cycling of the compressor by reducing the capacity by 50% when the process fluid temperature nears the setpoint.


I. HIGH/LOW PRESSURESTATS: the high/low pressurestats protect the refrigeration system from unsafe operating levels.

The **high pressure switch** is factory set and protects the refrigeration components and personnel from potential damage of



Adjustable high pressure switch

Brazed Plate Evaporator
 Compressor
 Liquid Line Solenoid Valve
 Filter Drier
 Liquid Receiver



injury from excessive high pressure. The high pressure safety must not be altered in the field for any reason. (See section 8.1 for factory settings.)



Adjustable low pressure switch

* See Temperature-Pressure chart in Section 8.5 for refrigerant pressure.

The **low pressure switch** is factory set to open at 32°F and to close at 36° - 39°F.* The low pressure switch protects the chillers from possible damage due to low operating pressure. The low pressure switch is field adjustable for setpoints below 48°F.

NEVER LOWER THE CUT OUT SETTING WITHOUT ADDING GLYCOL TO THE CIRCULATING SYSTEM. EVAPORATOR DAMAGE WILL RESULT AND WILL NOT BE COVERED BY THE WARRANTY.

- J. Liquid receiver:** Located after the air-cooled condenser, this component receives and stores liquid refrigerant leaving the condenser. (Air-cooled models only).
- K. Service valves:** Have been provided throughout the system. Only a qualified refrigeration service technician shall operate these valves.
- L. Crankcase heater:** Insures that freon and compressor crankcase oil do not mix during the compressor's "off" cycles. Power must be applied to the chiller previous to startup. (Not on all models.)
- M. Oil pressure safety switch:** protects the compressor from lubrication failure. (Not on all models.)

N. Pressure Gauges:

Compressor Discharge (Head) Pressure: Compressor discharge and refrigerant condensing pressure. Pressure operating range will vary depending on refrigerant type.

Compressor Suction (Low) Pressure: Compressor suction and refrigerant evaporating pressure. Pressure operating range will vary depending on refrigerant type.

6.2 COOLANT SYSTEM

- A. Reservoir:** Provides coolant storage during non operating periods. An internal baffle separates 'from process' and 'to process' fluid flows during operating periods.
- B. Process Pump:** Provides fluid to the central system.
- C. Standby Pump:** Optional pump to provide backup for the process or evaporator pump.
- D. Evaporator pump:** Provides consistent flow through the brazed plate evaporators to maintain full capacity.
- E. Flow switch:** Protects the evaporator from possible freezing caused by too little flow.
- F. Freezestat:** Protects the system from potential freezing. Factory adjusted to 40°F. For operating temperatures below 48°F, see section 6.7 on page 39.
- G. Level control switch:** Indicates water level in reservoir.




7.0 RELATED DRAWINGS

- 7.1** Typical Circuit Schematic
- 7.2** Typical Physical Drawing
- 7.3** Typical Press Drop
- 7.4** Typical Vacuum Breaker / Anti-Siphon System
- 7.5** Typical Label Placement Drawing
- 7.6** Typical Panel / Control Station Drawing




7.1 TYPICAL CIRCUIT SCHEMATIC




#	Item	#	Item	#	Item
1	From process connection	14	Process pump	28	Compressor discharge valve
2	Tank assembly	15	Supply pressure gauge	29	Condenser
3	Baffle plate	16	Alarm pressure switch	30	Service valve
4	Tank drain valve	17	To process connection	31	Head pressure gauge
5	Return probe	18	Standby pump	32	Filter-drier
6	Tank level control	19	Pump discharge valve	33	Liquid line solenoid valve
7	Level sight glass	20	Flow safety switch	34	Refrigerant sight glass
8	Overflow to drain	21	Factory adjusted flow control valve	35	Expansion valve
9	Pump suction valve	22	Evaporator	36	Hot gas by-pass valve
10	Evaporator pump	23	Freezestat	37	Evaporator out temperature sensor
11	Supply probe	24	Compressor suction valve	38	Evaporator in temperature sensor
12	Control sensor	25	Compressor		
13	Alarm thermostat	26	Low pressure safety switch		
		27	Low pressure gauge		

7.2 TYPICAL PHYSICAL DRAWING



7.3 TYPICAL PRESS DROP FOR INJECTION OR BLOW MOLDING




CONDITION	VALVES OPEN
WATER SUPPLY TO AUXILIARY EQUIPMENT	1,2,3,4
TO RUN TOWER WATER ON MOLD	5,6,9,10,11,12
TO RUN CHILLED WATER ON MOLD	7,8,11,12
TO RUN AUXILIARY EQUIPMENT ON MOLD	13,14
TO RUN TOWER WATER ON HEAT EXCHANGER	5,6,17,18
TO RUN CHILLED WATER ON HEAT EXCHANGER	7,8,15,16
TO RUN AUXILIARY EQUIPMENT ON HEAT EXCHANGER	19,20

- NOTES:
- 1) GPM @ 40 psig, 10°FΔT
 - 2) INSTALL SERVICE UNIONS AND GAUGES AS REQUIRED.
 - 3) INSULATE ALL CHILLED WATER PIPING.
 - 4) PIPE SIZES ARE BASED ON FLOW RATES AND PRESSURE REQUIREMENTS. (SEE SCHEDULE)
 - 5) SEE VALVE POSITION SCHEDULE FOR OPEN REQUIREMENTS (ALL OTHER VALVES ARE CLOSED). MORE THAN ONE CONDITION MAY EXIST AT ONE TIME, WITH THE EXCEPTION OF MIXING TOWER AND CHILLED WATER SYSTEMS.

This drawing is supplied to demonstrate a possible piping configuration for the equipment and is general in nature showing pipe sizes and basic routing. It is not intended to be inclusive of every detail required for specific location and installation. Consult with a professional engineer to determine specific needs before installation.



7.4 TYPICAL VACUUM BREAKER / ANTI-SIPHON SYSTEM





INSTALLATION NOTES:

1. The purpose of the vacuum breaker/anti-siphon (also called a drain-back dam), is to retain water in the header system during shut-down, and to eliminate air purge and shock to plumbing during start-up.
2. It is necessary to duplicate this arrangement on both the supply and return lines.
3. The drain-down valve allows header drainage for system maintenance and is closed during normal operation.
4. The vacuum breaker must be located at the highest point in the system, nearest to the tank to be most effective. A nipple length of 8 inches minimum is required to create sufficient vacuum to open the Cash Acme model VR-801.


7.5 TYPICAL LABEL PLACEMENT DRAWING

LP-1452	ITEM QTY	LABELS	DESCRIPTION	OACS-80AD 2842SF	
A	1	LIQUID LEVEL			
B	1	FILL PORT			
C	1	DRAIN			
D	1	HIGH VOLTAGE WARNING			
E	1	MADE IN AMERICA			
F	1	HIGH PRESSURE WARNING			
G	1	HEAD PRESSURE, ZONE #1			
H	1	LOW PRESSURE, ZONE #1			
I	1	HEAD PRESSURE, ZONE #2			
J	1	LOW PRESSURE, ZONE #2			
K	1	PRESSURE TO PROCESS			
L	1	ADVANTAGE LOGO			
M	1	TITAN LOGO			
N	1	TO PROCESS			
O	1	DATA TAG			
P	1	PROCESS PUMP			
Q	1	EVAPORATOR PUMP			
R	1	FROM PROCESS			
S	1	EMERGENCY STOP			
T	1	MASTER SWITCH OFF/ON			
U	1	POWER ON			
V	1	ALARM INACTIVE/ACTIVE			
W	1	FAULT			
X	1	PROCESS PUMP OFF/ON			
Y	1	PROCESS PUMP ON			
Z	1	PROCESS PUMP OVERLOAD			
AA	1	EVAP. PUMP OFF/ON			
BB	1	EVAP. PUMP ON			
CC	1	EVAP. PUMP OVERLOAD			
DD	1	SUMP HEATER ON			


LP-1452	ITEM QTY	LABELS	DESCRIPTION	OACS-80AD 2842SF
R	1	FROM PROCESS		
S	1	EMERGENCY STOP		
T	1	MASTER SWITCH OFF/ON		
U	1	POWER ON		
V	1	ALARM INACTIVE/ACTIVE		
W	1	FAULT		
X	1	PROCESS PUMP OFF/ON		
Y	1	PROCESS PUMP ON		
Z	1	PROCESS PUMP OVERLOAD		
AA	1	EVAP. PUMP OFF/ON		
BB	1	EVAP. PUMP ON		
CC	1	EVAP. PUMP OVERLOAD		
DD	1	SUMP HEATER ON		




TOP VIEW




SIDE VIEW



FRONT VIEW





SIDE VIEW




SIDE VIEW

7.7 TYPICAL PANEL CONTROL STATION DRAWING



ITEM	DESCRIPTION
A	INSTRUMENT: MZC-3
B	REFRIGERANT HIGH PRES. SWITCH, ZONE #1
C	REFRIGERANT LOW PRES. SWITCH, ZONE #1
D	REFRIGERANT HIGH PRES. SWITCH, ZONE #2
E	REFRIGERANT LOW PRES. SWITCH, ZONE #2
F	TERMINAL STRIP
G	BUS BAR
H	INSTRUMENT: MZC-3 ZONE BOARD, ZONE #1
I	INSTRUMENT: MZC-3 ZONE BOARD, ZONE #2
J	INSTRUMENT TRANSFORMER
K	FUSE BLOCK: FU-19,20
L	CONTROL TRANSFORMER
M	GROUND LUG
N	POWER DISTRIBUTION BLOCK
O	OIL PRESSURE SAFETY SWITCH, ZONE #1
P	OIL PRESSURE SAFETY SWITCH, ZONE #2
Q	SOLID STATE TIME DELAY RELAY: TANK LEVEL
R	SOLID STATE TIME DELAY RELAY: HEATER
S	RELAY: LOW LEVEL (R1)
T	RELAY: ALARM/FAULT (R2)
U	FUSE BLOCK: FU-16,17,18
V	FUSE BLOCK: FU-13,14,15
W	FUSE BLOCK: FU-10,11,12



ITEM	DESCRIPTION
X	FUSE BLOCK: FU-7,8,9
Y	FUSE BLOCK: FU-4,5,6
Z	FUSE BLOCK: FU-1,2,3

ITEM	DESCRIPTION
AA	HEATER CONTACTOR: H1
BB	COMPRESSOR CONTACTOR: M4
CC	COMPRESSOR CONTACTOR: M3
DD	MOTOR STARTER: M2
EE	MOTOR STARTER: M1



THIS PAGE INTENTIONALLY BLANK

8.0 APPENDIX

- 8.1** Operating Below 48°F Fluid or 38°F Ambient
- 8.2** Refrigerant Pressure-Temperature Chart
- 8.3** Inhibited Propylene Glycol
- 8.4** Chiller Capacity and Derate Chart
- 8.5** Standard CG Instrument Settings
- 8.6** Probe Calibration : CG Instrument
- 8.7** Status Indicators : CG Instrument
- 8.8** Water Quality
- 8.9** Modbus Registers



8.1 OPERATIONS BELOW 48°F FLUID OR 38°F AMBIENT

- A. The chiller is never to be operated below 48°F leaving water temperature without several precautionary measures. All controls are factory adjusted for 48°F and above operations.
- B. Before readjusting the protective devices, a satisfactory antifreeze solution must be substituted for the recirculating chilled water. This mixture will consist of inhibited propylene glycol and water. Do not substitute an inhibited propylene glycol and water solution with common automotive type antifreeze. The chart on the next page outlines the glycol percentages at various water temperatures.
- C. Fluid must be tested with a refractometer to verify proper glycol percentages for freeze protection. The ratio shall be according to the chart below. Too much glycol can cause capacity and control problems.
- D. **DO NOT USE AUTOMOTIVE TYPE ANTI-FREEZE.**
- E. **Once a satisfactory antifreeze solution is in place the protective devices may be adjusted and the control instrument can be unlocked to allow operation below 48°F.**
- F. If your unit is equipped with an adjustable low pressure switch, adjust the low pressure switch according to the specifications in the chart on the next page.

Never lower the cut out setting on the adjustable low pressure switch without adding glycol to the circulating system. Evaporator damage will result and this damage is not covered by the factory warranty.



Adjustable low pressure switch

- G. If your unit is equipped with a non-adjustable “fixed” pressure switch with a factory low limit of 48°F this switch must be replaced with a switch with a lower limit. The lower range low pressure switch can be obtained from the factory by calling 317-887-0729 and asking for the service department. The model and serial number of your unit is required. A qualified refrigeration technician is required to change the switch though no gas recovery is required. The switch attaches to a threaded fitting on the refrigeration line.
- H. Once all limit switches are adjusted, the temperature control instrument may be lowered to the desired operating temperature. Your control instrument may require moving a jumper or DIP switch to allow the temperature set points below 48°F. See the control instrument section of this manual or call the Advantage service department for specific instructions.
- I. **LE Instruments.** The LE instrument requires an adjustment of the DIP switch to accommodate the expanded temperature range. Please see section 5.6 in this manual for more information.
- J. **Multizone Instruments.** The Multizone instrument requires an adjustment of the DIP switch to accommodate the expanded temperature range. Please see section 5.7 in this manual for more information.



Fixed low pressure switch

- K. Once all safety provisions are made, the temperature control set point may now be lowered to the desired operating temperature.
- L. **WARNING:** do not use any type or brand of automotive antifreeze. Automotive antifreeze contains corrosion inhibitors - silicates - designed for compatibility with the materials in automotive engines. Unfortunately, silicates can gel and cause deposits to foul and insulate heat exchanger surfaces. In your chilling system that can mean higher energy costs, high pumping costs, and possibly even shut downs for system cleaning. We recommend the use of DowFrost or Monsanto DFS-1.

Refrigerant Low Pressure Switch Cut-Out & Cut-In Settings

Ambient Temperature	Operating Temperature	Glycol	Freeze Point	Cut Out Temp	Cut In Temp	R22		R134A		R410A	
						Cut-Out	Cut-In	Cut-Out	Cut-In	Cut-Out	Cut-In
39°F +	48° - 70°F	0%	32°F	32°F	36°F - 39°F	58#	63#	28#	33#	102#	111#
15° to 38°F	25° - 47°F	30%	10°F	10°F	15°F - 18°F	33#	38#	12#	17#	63#	72#
0° to 14°F	10° - 24°F	40%	-5°F	-5°F	0°F - 7°F	20#	25#	4#	9#	43#	52#
-10° to 0°F	n/a	45%									
-20° to -10°F	n/a	50%									

Ambient Temperature	Operating Temperature	Glycol	Freeze Point	Cut Out Temp	Cut In Temp	R404A		R407C	
						Cut-Out	Cut-In	Cut-Out	Cut-In
39°F +	48° - 70°F	0%	32°F	32°F	36°F - 3°9F	72#	79#	52#	58#
15° to 38°F	25° - 47°F	30%	10°F	10°F	15°F - 1°8F	44#	49#	28#	34#
0° to 14°F	10° - 24°F	40%	-5°F	-5°F	0°F - 7°F	29#	34#	16#	22#
-10° to 0°F	n/a	45%							
-20° to -10°F	n/a	50%							

High Pressure Cut Out (maximum) (with liquid receiver)

Refrigerant	Air-Cooled
R22	360#
R134A	260#
R407C	360#
R410A	550#
R404A	360#



8.2 REFRIGERANT PRESSURE-TEMPERATURE CHART

Refrigerant Pressure Temperature Chart

Temperature		Refrigerant						Temperature		Refrigerant				
°F	°C	R-22	R-410a	R-407c	R-134a	R-404a		°F	°C	R-22	R-410a	R-407c	R-134a	R-404a
-60	-51.1	<i>11.9</i>	<i>0.9</i>	<i>16.0</i>	<i>21.6</i>	-	27	-2.8	51.2	91.6	44.7	23.7	66.2	
-55	-48.3	<i>9.2</i>	1.8	<i>13.7</i>	<i>20.2</i>	-	28	-2.2	52.4	93.5	45.9	24.5	67.7	
-50	-45.6	<i>6.1</i>	4.3	<i>11.1</i>	<i>18.6</i>	-	29	-1.7	53.7	95.5	47.1	25.3	69.2	
-45	-42.8	<i>2.7</i>	7.0	<i>8.1</i>	<i>16.7</i>	-	30	-1.1	54.9	97.5	48.4	26.1	70.7	
-40	-40.0	0.6	10.1	<i>4.8</i>	<i>14.7</i>	4.9	31	-0.6	56.2	99.5	49.6	26.9	72.1	
-35	-37.2	2.6	13.5	<i>1.1</i>	<i>12.3</i>	7.5	32	0.0	57.5	101.6	50.9	27.8	73.8	
-30	-34.4	4.9	17.2	1.5	<i>9.7</i>	10.3	33	0.6	58.8	103.6	52.1	28.6	75.3	
-25	-31.7	7.5	21.4	3.7	<i>6.8</i>	13.5	34	1.1	60.2	105.7	53.4	29.5	76.9	
-20	-28.9	10.2	25.9	6.2	<i>3.6</i>	16.8	35	1.7	61.5	107.9	54.8	30.4	78.5	
-18	-27.8	11.4	27.8	7.2	<i>2.2</i>	18.3	36	2.2	62.9	110.0	56.1	31.3	80.2	
-16	-26.7	12.6	29.7	8.4	<i>0.7</i>	19.8	37	2.8	64.3	112.2	57.5	32.2	81.7	
-14	-25.6	13.9	31.8	9.5	0.4	21.3	38	3.3	65.7	114.4	58.9	33.1	83.5	
-12	-24.4	15.2	33.9	10.7	1.2	22.9	39	3.9	67.1	116.7	60.3	34.1	85.2	
-10	-23.3	16.5	36.1	11.9	2.0	24.6	40	4.4	68.6	118.9	61.7	35.0	86.9	
-8	-22.2	17.9	38.4	13.2	2.8	26.3	41	5.0	70.0	121.2	63.1	36.0	88.6	
-6	-21.1	19.4	40.7	14.6	3.7	28.0	42	5.6	71.5	123.6	64.6	37.0	90.4	
-4	-20.0	20.9	43.1	15.9	4.6	29.8	43	6.1	73.0	125.9	66.1	38.0	92.2	
-2	-18.9	22.4	45.6	17.4	5.5	31.7	44	6.7	74.5	128.3	67.6	39.0	94.0	
0	-17.8	24.0	48.2	18.9	6.5	33.7	45	7.2	76.1	130.7	69.1	40.0	95.8	
1	-17.2	24.8	49.5	19.6	7.0	34.7	46	7.8	77.6	133.2	70.6	41.1	97.6	
2	-16.7	25.7	50.9	20.4	7.5	35.7	47	8.3	79.2	135.6	72.2	42.2	99.5	
3	-16.1	26.5	52.2	21.2	8.0	36.7	48	8.9	80.8	138.2	73.8	43.2	101.4	
4	-15.6	27.4	53.6	22.0	8.6	37.7	49	9.4	82.4	140.7	75.4	44.3	103.3	
5	-15.0	28.3	55.0	22.8	9.1	38.8	50	10.0	84.1	143.3	77.1	45.4	105.3	
6	-14.4	29.1	56.4	23.7	9.7	39.8	55	12.8	92.6	156.6	106.0	51.2	115.3	
7	-13.9	30.0	57.9	24.5	10.2	40.9	60	15.6	101.6	170.7	116.2	57.4	126.0	
8	-13.3	31.0	59.3	25.4	10.8	42.0	65	18.3	111.3	185.7	127.0	64.0	137.4	
9	-12.8	31.9	60.8	26.2	11.4	43.1	70	21.1	121.5	201.5	138.5	71.1	149.3	
10	-12.2	32.8	62.3	27.1	12.0	44.3	75	23.9	132.2	218.2	150.6	78.6	161.9	
11	-11.7	33.8	63.9	28.0	12.6	45.4	80	26.7	143.7	235.9	163.5	86.7	175.4	
12	-11.1	34.8	65.4	29.0	13.2	46.6	85	29.4	155.7	254.6	177.0	95.2	189.6	
13	-10.6	35.8	67.0	29.9	13.8	47.8	90	32.2	168.4	274.3	191.3	104.3	204.5	
14	-10.0	36.8	68.6	30.9	14.4	49.0	95	35.0	181.9	295.0	206.4	113.9	220.2	
15	-9.4	37.8	70.2	31.8	15.1	50.2	100	37.8	196.0	316.9	222.3	124.1	236.8	
16	-8.9	38.8	71.9	32.8	15.7	51.5	105	40.6	210.8	339.9	239.0	134.9	254.2	
17	-8.3	39.9	73.5	33.8	16.4	52.7	110	43.3	226.4	364.1	256.5	146.3	272.5	
18	-7.8	40.9	75.2	34.8	17.1	54.0	115	46.1	242.8	389.6	274.9	158.4	291.9	
19	-7.2	42.0	77.0	35.9	17.7	55.3	120	48.9	260.0	416.4	294.2	171.1	312.1	
20	-6.7	43.1	78.7	36.9	18.4	56.6	125	51.7	278.1	444.5	314.5	184.5	333.4	
21	-6.1	44.2	80.5	38.0	19.2	57.9	130	54.4	297.0	474.0	335.7	198.7	355.6	
22	-5.6	45.3	82.3	39.1	19.9	59.3	135	57.2	316.7	505.0	357.8	213.5	379.1	
23	-5.0	46.5	84.1	40.2	20.6	60.6	140	60.0	337.4	537.6	380.9	229.2	403.7	
24	-4.4	47.6	85.9	41.3	21.4	62.0	145	62.8	359.1	571.7	405.1	245.6	429.6	
25	-3.9	48.8	87.8	42.4	22.1	63.4	150	65.6	381.7	607.6	430.3	262.8	456.8	
26	-3.3	50.0	89.7	43.6	22.9	64.8	155	68.3	405.4	645.2	456.6	281.0	484.8	

Italics indicates vacuum (inches of mercury)

Standard font indicates pressure (pounds per inch gauge)



8.3 INHIBITED PROPYLENE GLYCOL

- A.** To operate liquid chillers below 48°F, it is necessary to add **inhibited propylene glycol** to the circulating system to lower the freeze point and prevent damage to the cooling system. Inhibited propylene glycol contains corrosion inhibitors which are compatible with most industrial heat transfer surfaces. Inhibited propylene glycol is manufactured by:
- Dow Chemical - "DowFrost" (1-800-258-2436)
 - Monsanto "Therminol FS" (1-800-459-2665)
 - Advantage Engineering "Thermofluid" (1-317-887-0729)
- B.** Automotive anti-freeze must never be used in industrial heat transfer applications. Automotive anti-freeze contains silicate type corrosion inhibitors designed to be compatible with automotive components. In an industrial application, the silicates will form a gel on the heat transfer surface which will result in substantial reduction in cooling capacity and is virtually impossible to remove.

8.4 CHILLER CAPACITY AND DERATE CHART

- A.** Standard chiller rating is at 50°F. For all other temperature settings, output tonnage is altered as follows:

OUTPUT TEMPERATURE °F	FULL AVAILABLE % CAPACITY
60	105%
50	100%
45	90%
40	80%
35	70%
30	60%
25	50%
20	40%

- B.** If operation of the chiller at less than 48°F is required, an inhibited propylene glycol solution is required.
- C.** Consult factory for chiller operation below 20°F.
- D.** Ambient conditions affect air cooled chiller operation and capacity. Standard rating is at 95°F entering air temperature. For ambient air conditions greater than 95°F, chiller derating will occur. For ambients over 95°F consult factory.



8.5 STANDARD CG INSTRUMENT SETTINGS

- A. Caution: See section 8.1 for proper settings based on your fluid set point temperature.

Adjustable Low Pressure Cut Out Range

- 9 PSI to 150 PSI
-

Adjustable Low Pressure Cut In Range

- 19 PSI to 150 PSI
-

Adjustable High Pressure Cut Out Range

- 225 PSI to 580 PSI
-



8.6 PROBE CALIBRATION : CG Instrument

A. Equipment Needed:

1. Potentiometer adjustment tool / flat-blade screw driver (tip width of 0.050" or less works best)
2. Temperature reference (ice water bath)
3. 1/2" plug
4. Digital thermometer
5. Screwdriver (chassis disassembly)

B. Setup:

1. Disengage process operations according to the procedure outlined in the unit manual. The operator must be certain all system pressure is relieved and unit pressure gauges read "0".
2. Following all lock-out-tag-out procedures disengage main power supply.
3. Remove the "to process" temperature probe and insert a 1/2" plug in its place.
4. Prepare an ice bath (a cup of water with lots of ice). You should place a digital thermometer in the ice bath to read the temperature of the bath. Place the probe in the ice bath.


C. Procedure:

1. Restart the instrument according to the procedures outlined in the unit manual.
2. Reduce the unit's setpoint to its lowest setting.
3. The "to process" temperature on the display should equal the temperature of the ice bath as indicated by the digital thermometer. If not, change the calibration.
4. The calibration potentiometer is located on the top of the CPU board. To access it, open the electrical cabinet panel door. Caution must be employed when the electrical panel door is open since power is applied to unit.
5. Locate the "to process" calibration potentiometer using Figure 1 as a guide. Use the small screwdriver to turn the potentiometer.
6. Adjust the potentiometer until the "to process" temperature on the display equals the temperature of the ice bath.
7. When the two temperatures are equal, the calibration procedure is complete.
NOTE: the optional "from process" probe has its own calibration potentiometer.



If calibration of this probe is required, repeat the setup and calibration procedure with the “from process” probe. A from process probe may not be included with your chiller.


8. Stop the unit following the shutdown procedure described in the manual and place all process probes back in the unit to return to normal operation.




8.7 STATUS INDICATORS : CG INSTRUMENT

- A. The control instrument is configured at the Factory for the type and number of compressors and type of capacity unloading mechanism.
- B. Shown below are possible Status Indicators displays for various compressor and capacity unloading set ups.

Typical display for chillers with a single compressor (digital scroll or scroll) and digital or hot gas bypass capacity unloading.




Typical display for chillers with two compressors (digital scroll or scroll) and digital or hot gas bypass capacity unloading.



Typical display for chillers with a discus compressor and a capacity unloader.



Typical display for chillers with a screw compressor showing capacity at 50% and 75%. The fourth indicator will pulse on for 10 seconds then off for 10 seconds indicating proper compressor operation.



8.8 WATER QUALITY

- A.** Lack of as well as improper water treatment can damage to your equipment. The equipment owner is responsible to prevent equipment damage from foreign material or inadequate water treatment. The services of a competent water treatment specialist should be obtained and his recommendations followed. For small systems, a local swimming pool supply is an excellent source of analysis service and chemical supplies. An alternative is the addition of 20% inhibited propylene glycol. This will inhibit corrosion, algae growth and prevent accidental freeze ups.

Sources For Inhibited Propylene Glycol

- Therminol FS Monsanto Chemical 1-800-459-2665
- Dowfrost Dow Chemical 1-800-447-4369

FREEZING POINTS FOR WATER/PROPYLENE GLYCOL SOLUTIONS

PERCENTAGE OF GLYCOL* WATER		FREEZE POINT °F °C	
0	100	32	0
10	90	25	-3.9
20	80	10	-12.2
30	70	0	-17.8
40	60	-10	-23.3
50	50	-30	-34.4
60	40	-60	-51.4

*Propylene Glycol
Note: Glycol freeze point must be 25°F below lowest setpoint.

- B.** The following are guidelines specific to chillers with an internal circulation pump and fluid reservoirs.
- C.** Long term performance of your chiller will be adversely affect by poor water conditions. The three major problems water treatment must address are:

1. Scaling

- a.** Scaling of the heat transfer surfaces due to minerals can be minimized by proper treatment and filtering of the make-up water. A good quality of water must be used.
- b.** The recommended purity levels are:
- | | |
|-----------|------------|
| Chlorides | 25 ppm max |
| Sulfates | 25 ppm max |
| Calcium | 50 ppm max |
| Magnesium | 50 ppm max |
| PH level | 8 to 10 |
- c.** Although not mandatory, distilled water would be an excellent choice for filling the system.




2. Corrosion

1. Corrosion is usually the result of acidic water (improper PH control). This can be controlled by proper chemical treatment.



3. Algae

1. Algae (organism growth) can be controlled by the proper use of chemical treatment.



8.9 MODBUS REGISTERS

	Register	Coil	Use	Range	Units	Notes	* Low water level is defined but not implemented and will never trigger																	
Temperature Setpoint	1		R/W	0 - 250	F																			
Reserved	2																							
Temperature High Alarm	3		R/W	0 - 50	F	Deviation Value																		
Temperature Low Alarm	4		R/W	0 - 50	F	Deviation Value																		
Low Flow Alarm	5		R/W	0 - 255	GPM	Absolute Value																		
To Process Temperature	6		R	0 - 255	F																			
From Process Temperature	7		R	0 - 255	F																			
Flow	8				GPM																			
Process Status	9	1 thru 16	R				Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0		
													Low Flow				Low Temp	Hi Temp	Alarm Machine	Alarm Process	Alarm	0		
Machine Status 1	10	17 thru 32	R				Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0		
								Phase Wrong		MOL Evap Pump			Low Flow		Low Ref Pressure	High Ref Pressure	Low Temp		Alarm Machine	Alarm Process	Alarm	0		
Machine Status 2	11	33 thru 48	R				Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0		
																		Sensor Fail	Alarm Machine	Alarm Process	Alarm	0		
Machine Status 3	12	49 thru 64	R				Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0		
																		MOL Evap Pump	MOL Proc Pump	Low Water Level	Alarm Machine	Alarm Process	Alarm	0
	13	65 thru 80	R																					
	14	81 thru 96	R																					
	15	97 thru 112	R																					
Machine Control	16	113 thru 128	R/W				Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0		
																					Alarm Ack.	On/Off		
Reserved	17																							
Reserved	18																							
Reserved	19																							
Reserved	20																							
Reserved	21																							
Reserved	22																							
Status	23	257 thru 272					Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0		
							1	Reserved	Output 4	Output 3	Output 2	Output 1	Reserved	Reserved	1	Running	Comp. Overload	Low Oil Pressure	Reserved	High Ref. Pressure	Low Ref. Pressure	Low Water Flow		
Reserved	24																							
Reserved	25																							
Reserved	26																							
Reserved	27																							
Reserved	28																							
Low Refrig Suction Pressure	29		R		PSI																			
High Refrig Discharge Pressure	30		R		PSI																			
To Process Water	31		R		PSI																			
Reserved	32		R																					
Reserved	33		R																					
Reserved	34		R																					
Reserved	35		R																					
Reserved	36		R																					
Reserved	37		R																					
Reserved	38		R																					
Reserved	39		R																					
Reserved	40		R																					



END

© 2021 Temptek, Inc.

RE 20210813

